

## Features


- A compact size servo motor with large through hole for wiring and piping.
- Positioning using standard Pulse train command.
- Auto Tuning Function for easy start up.

## Typical applications

- Replacing Gear reducer and AC servo motor with Direct Drive motor.
- Reducing size and envelope of conventional positioning/transfer system.


## Line up

Maximum output torque




## Application

Inspection equipment for electronic parts



- High speed and high accuracy
- Compact
- Clean
- Hollow structure (convenient for wiring/tubing)

High-speed conveyance of lightweight parts




- High speed and high accuracy
- Clean
- Maintenance free
- Hollow structure (convenient for wiring/tubing)

## Advantage of Direct Drive Motor

The highly precise positioning which has no backlashes or lost motions is achieved. Because MEGATORQUE MOTOR is directly connected with a load without using reduction gears. Long term maintenance free is achieved by using a grease prelubricated bearing.

- Positioning accuracy** Non backlash, high precisions positioning
- Positioning time** Short cycle time
- Deterioration with age** No performance degradation due to aging
- Maintenance** Long term maintenance free
- Compact** NSK motor allows users to design compact and lightweight system

# 1 System configuration



## Combination table

| Motor Reference No. | Converter Reference No. | Driver Reference No. | Motor cable Reference No.   | Converter cable Reference No.   |
|---------------------|-------------------------|----------------------|---|---|
| M-PB1006JN001       | M-ECC-PB1006GA201       | M-EGA-15A2301        | M-CA***A101<br>***: cable length<br>002 : 2 [m]<br>004 : 4 [m]<br>008 : 8 [m] | M-CC***A101<br>***: cable length<br>002 : 2 [m]<br>004 : 4 [m]<br>008 : 8 [m] |
| M-PB3015JN001       | M-ECC-PB3015GA201       |                      |   |   |
| M-PB3030JN001       | M-ECC-PB3030GA201       |                      |   |   |
| M-PB3060JN001       | M-ECC-PB3060GA201       | M-EGA-30A2301        |   |   |

## Accessories

| Name                   | Reference No. | Remarks                           |
|------------------------|---------------|-----------------------------------|
| Power connector        | M-FAE0001     | CNA connector                     |
| IO connector           | M-FAE0002     | CN1 connector                     |
| Mounting bracket       | M-FAE0003     | Front mounting bracket for Driver |
| Regenerative resistor  | M-FAE0004     | 80 [W]                            |
| Regenerative resistor  | M-FAE0005     | 220 [W]                           |
| PC communication cable | M-FAE0006     | Cable length : 2 850 [mm]         |
| Connector set          | M-FAE0007     | CNA and CN1                       |

# 3 Driver

## 3.1. Driver Reference number

Example of Reference number : **M-EGA - 15 A 2 3 01**

Driver Model EGA  
 Maximum output current 15 : 15 [Arms]  
 30 : 30 [Arms]  
 Power voltage A : 200to230 [VAC] (Single phase/Three phase)  
 Design number 01 : Standard  
 Function 3 : Pulse train input  
 Position sensor code 2 : Incremental



## 3.2. Specifications

### 3.3.1. General specifications

| Functional item              | M-EGA-15A2301   | M-EGA-30A2301   |
|------------------------------|---|---|
| Control function             | Position control  |   |
| Control system               | IGBT: PWM control Sinusoidal drive  |   |
| Main circuit power           | Three phase   | 200 to 230 [VAC] +10/-15 [%] , 50/60 [Hz] ] +/-3 [Hz]                               |
|                              | Single phase  | 200 to 230 [VAC] +10/-15 [%] , 50/60 [Hz] +/-3 [Hz]                                 |
| Control power                | 200 to 230 [VAC] +10/-15 [%] , 50/60 [Hz] +/-3 [Hz]   |   |
| Power capacity               | Main Power (Rated)  | M-PB1006JN001 : 0.3 [kVA]<br>M-PB3015JN001 : 0.5 [kVA]<br>M-PB3030JN001 : 1.0 [kVA] |
|                              | Control Power   | 40 [VA]   |
| Environment                  | Operating temperatures  | 0 to 55 [°C]  |
|                              | Storing temperatures  | -20 to +65 [°C]   |
|                              | Operating/Storing humidity  | Below 90 [%RH] (No condensation)  |
|                              | Elevation   | Below 1,000 [m]   |
|                              | Vibration   | 4.9 [m/s <sup>2</sup> ]   |
|                              | Shock   | 19.6 [m/s <sup>2</sup> ]  |
| Dimensions (HxWxD)           | 160x40x130 [mm]   | 160x50x130 [mm]   |
| Mass                         | 0.75 [kg]   | 0.9 [kg]  |
| Alarms                       | Over current, Current detection error, Over load, Regeneration error, Driver overheating, External overheating, Over voltage, Main circuit power low voltage, Main circuit power supply open phase, Control power supply low voltage, Encoder error, Over speed, Speed control error, Speed feedback error, Excessive position, Positioning command pulse error, Built-in memory error, Parameter error |   |
| Digital operator             | Status display, Monitor display, Alarm display, Parameter setting, Test operation, Adjustment mode  |   |
| Dynamic brake circuit        | Built-in  |   |
| Regeneration process circuit | Built-in *  |   |
| Monitors                     | Speed monitor (VMON)  | 2.0 [V] +/-10 [%] (at 1,000 [min <sup>-1</sup> ])                                   |
|                              | Torque (TCMON)  | 2.0 [V] +/-10 [%] (at 100 [%])  |


\* Please refer 6.Accessories in case of Regenerative resistor is required.

### 3.3.2. Input command, position feedback signal output, general input, general output


|   |   |  |
|---|---|--|
| Position command  | Maximum input pulse frequency   | 5 [Mpps] (CW+CCW pulse, Code + Pulse train)<br>1.25 [Mpps] (90 [°] -phase difference two-phase pulse)        |
|   | Input pulse form  | CW + CCW command pulse, Code + Pulse train command or 90 [°] -phase difference two-phase pulse train command |
|   | Electronic gear   | N/D (N=1 to 2,097,152, D=1 to 2,097,152)<br>however, 1/2,097,152 ≤ N/D ≤ 2,097,152                           |
| Position feedback signal  | A/B phase pulse output: N/32,768 (N=1 to 32,767), 1/N (N=1 to 64) or 2/N (N=3 to 64)<br>Z phase pulse output : 80 [count / rev]   |  |
| Sequence input  | Interactive photo coupler (sink, source connection): 6 inputs   |  |
|   | Line receiver: 2 inputs   |  |
| Sequence output   | Input power voltage range: 5 [VDC] +/- 5 [%] / 12 to 24 [VDC] +/- 10 [%], 100[mA] or over   |  |
|   | Servo on, Alarm reset, Torque limit, CW rotation prohibit, CCW rotation prohibit, Command prohibit, Forced discharge, Emergency stop, Gain switching, Internal speed setting, Start of estimation of magnetic pole position, etc. |  |
|   | Open collector output: 8 outputs  |  |
|   | External power supply voltage (OUT-PWR): 5 [VDC] +/- 5 [%] / 12 to 24 [VDC] +/- 10 [%], 20 [mA] or over   |  |
| Sequence output   | Circuit power for output signal: 5 [VDC] +/- 5 [%] / Max. 10 [mA] (per 1 output)  |  |
|   | Circuit power for output signal: 12 to 15 [VDC] +/- 10 [%] / Max. 30 [mA] (per 1 output)  |  |
|   | Circuit power for output signal: 24 [VDC] +/- 10 [%] / Max. 50 [mA] (per 1 output)  |  |
| Servo ready, Power on, Servo on, Torque limiting, Speed limiting, Low speed, Velocity attainment, Matching speed, Zero speed, Command acceptable, Status of gain switch, Velocity loop proportional control status, CW Over Travel, CCW Over Travel, Warning, Alarm code (3 bit), Start of estimation of magnetic pole position, etc. |   |  |

## 3.2. Dimension

M-EGA-15A2301



M-EGA-30A2301




3.4. CN1 Signal and function

| Terminal number | Signal name       | Description               |
|-----------------|-------------------|---------------------------|
| 1               | —                 | Do not connect            |
| 2               | —                 | Do not connect            |
| 3               | AO                | A phase pulse output      |
| 4               | $\overline{AO}$   | /A phase pulse output     |
| 5               | BO                | B phase pulse output      |
| 6               | $\overline{BO}$   | /B phase pulse output     |
| 7               | ZO                | Z phase pulse output      |
| 8               | $\overline{ZO}$   | /Z phase pulse output     |
| 9               | PS                | Resolver signal output    |
| 10              | $\overline{PS}$   | /Resolver signal output   |
| 11              | ZOP               | Z phase pulse output      |
| 12              | SG                | Common for pins 3 to 11   |
| 17              | —                 | Do not connect            |
| 18              | —                 | Do not connect            |
| 19              | —                 | Do not connect            |
| 20              | —                 | Do not connect            |
| 21              | —                 | Do not connect            |
| 22              | T-COMP            | Torque compensation input |
| 23              | SG                | Common for pin 22         |
| 26              | F-PC              | CW command pulse input    |
| 27              | $\overline{F-PC}$ | CW command pulse input    |
| 28              | R-PC              | CCW command pulse input   |
| 29              | $\overline{R-PC}$ | CCW command pulse input   |
| 47              | SG                | Common for pins 26 and 27 |
| 48              | SG                | Common for pins 28 and 29 |
| 30              | MON1              | Analog monitor output     |
| 31              | SG                | Common for pin 30         |

| Terminal number | Signal name        | Description   |
|-----------------|--------------------|---|
| 13              | CONT7              | Position command pulse disabled function/shutdown at zero velocity function |
| 14              | $\overline{CONT7}$ |   |
| 15              | CONT8              | Alarm reset function  |
| 16              | $\overline{CONT8}$ |   |
| 38              | SG                 | Common for pins 13 to 16  |
| 32              | CONT6              | CW over travel function   |
| 33              | CONT5              | CCW over travel function  |
| 34              | CONT4              | Deviation clear function  |
| 35              | CONT3              | Magnetic pole position estimation input                                     |
| 36              | CONT2              | Emergency stop function   |
| 37              | CONT1              | Servo-ON function   |
| 50              | CONT-COM           | General input power supply  |
| 39              | OUT1               | In-Position window  |
| 40              | OUT2               | Magnetic pole position estimation ready                                     |
| 41              | OUT3               | Operation setup completion  |
| 42              | OUT4               | Magnetic pole position estimation end                                       |
| 43              | OUT5               | Alarm code bit 5  |
| 44              | OUT6               | Alarm code bit 6  |
| 45              | OUT7               | Alarm code bit 7  |
| 46              | OUT8               | Alarm status  |
| 49              | OUT-PWR            | Power source for general output   |
| 24              | OUT-COM            | General output Common   |
| 25              | OUT-COM            | General output Common   |

· Terminal number 26 to 29: CW + CCW pulse command, Code + pulse train command or 90 [°] -phase difference two-phase pulse train command can be selected.  
 · Terminal number 13 to 16, 32 to 37: Shipping set  
 · Terminal number 39 to 46: Shipping set

3.5. Pulse train input signal specifications





4 Cable

4.1. Motor cable

4.1.1. Motor cable Reference number 4.1.2. Dimension



Example :



4.2. Converter cable

4.2.1. Converter cable Reference number 4.2.2. Dimension

Example :




5 Converter

5.1. Converter Reference Number

Example : M-ECC - PB1006 GA 2 01



5.2. Dimension



\*Converter must be installed to stationary part.